

# STEALTH SCREEN

## APPLICATION INSTRUCTIONS

1

Wipe down outside of window to remove dirt and dust, creating a dry, clean surface.

2

Peel off only the heavy white paper exposing black adhesive.

3

Apply Stealth Screen to the outside of your Stump window.

4

Use a flat surface to remove any air bubbles.

5

Peel off remaining paper to expose camouflage.

6

Use a utility knife to trim edges so they fit the shape of the window.

7

Repeat for remaining windows.

