

# WILD WATER® 300

---

## INCLUDED PARTS:

(2) 3' Trough (s)	(1) 300 Gallon Tank
(1) 2" Plug	(2) Float Valves
(2) Float Valve Protection Covers	(8) 1 3/4" Cover Bolts

1. Set your troughs on level ground.
2. Set your tank on level ground over the top of the troughs.
3. Install the 2 float valves to the outlet holes on the Wild Water tank.
4. Fill the tank through the 2" hole.
5. After the tank is full, insert the 2" plug into the fill hole.
6. Allow water to fill into the trough until it automatically shuts itself off. Water should not overflow the troughs. If water does proceed over the top of the troughs, verify that the troughs are level.
7. Install the 2 float valve protection covers with the (8) 1 3/4" bolts.

